



**4X4 EXHAUST
EXTREME DUTY**

redback4x4.com.au

Application: TLX441700-PB

Fitting Instructions For 79 Series Single and Double Cab V8 Twin System

1. Remove and retain the o² sensor from the standard exhaust.
2. Remove rear tail pipe / muffler from vehicle.
3. Remove intermediate pipe from vehicle and retain the 10mm bolts and springs.
4. Fit right hand side tail pipe support bracket to the two towbar mount holes. If vehicle is not fitted with a tow bar fit the supplied spacer between the bracket and the chassis rail. Refer Figure 1.



Figure 1.

5. Remove the large grey connector from its standard mounting position located forward of the fuel tank on the driver's side and secure it to the wiring loom above using the supplied cable ties. Connector shown in figure 2.



Figure 2.

6. Remove wiring bracket located forward of the fuel tank on the driver's side of the vehicle shown in figure 3 and secure the wiring with the cable ties supplied.



MANUFACTURING

1300 351 730

For your nearest
Authorised Dealer

www.redback4x4.com.au